



- 4ch High Speed Simultaneous Sampling
- CAT III 600V Compatible
- Measure AC 600 V Measurement with True-rms
- Built-in High-capacity RAM (4 M sampling/ch) and Flash memory (4 GB)
- Large Easy-to-read 7-inch LCD

Typical applications


Flow rate and temperature test in water heaters




Performance test of inverters for air conditioner



 Thermal insulation performance measurement of residential housing




Voltage and temperature measurement of generators



High speed 1 MS/s simultaneous sampling with isolated input

GL2000 is equipped with an isolated input mechanism to protect signals from interferences caused by noise from other channels. 16-bit A/D converter adopted to achieve hi-speed and hi-resolution measurement.



Simultaneous sampling

Sampling interval : 1 µs to 1 min (in steps of 1, 2, 5)

GL2000 utilizes simultaneous sampling to eliminate slowdown in sampling rate by using multiple A/D converters in simultaneous sampling method.

Four individual A/D converters in each channel sustains the maximum sampling speed for all four channels to measure high speed rapid voltage fluctuation and multi-channel vibration measurement.

External sampling function Maximum input frequency: 100 kHz

Sampling of the logger is performed in sync with an external device using an external signal input.

* B-513 Input/Output cable for GL is required.

Multifunction input with CAT III measurement category

Voltage, temperature, humidity, logic and pulse measurements can all be taken simultaneously in high speed.

Pulse/Logic

Pulse: 4ch (Instant, Accumulating, RPM)

Logic: 4ch


- * Select either Pulse or Logic. * Required input/output cable for GL (B-513 option).

Screw terminal (size M3.5)

Thermocouple: K, J, E, T, R, S, B, N, W(WRe5-26)


Humidity : 0 to 100 % * Required humidity sensor (B-530 option).

- ** . ٥ 9 **Isolated BNC connector** CAT III 600 V Voltage (DC) : 20 mV to 1000 V, 1-5 V Voltage (RMS): 10 mV to 1000 V rms * Maximum rated safety voltage: ± 600 V DC or 600 V rms
- * Connection can be made individually to BNC or screw terminal. BNC and screw terminal are connected to the same channel.
- CAT III 600 V is compatible with measuring power supply circuit in an equipment that captures power directly from the distribution panel.
- CATIII **CAT IV** CATIV CAT II CAT II **CAT IV** >00 Office or house Factory
- Measures abnormalities in a repeated waveform by effectively measuring the corresponding RMS value
 - In 1000 Vrms range, Crest Factor is up to 1.41 * Maximum rated safety voltage: 600 V rms, Peak voltage: 850V
 - In other range, Crest Factor is up to 2.0



Scaling (Engineering unit) function

Measured voltage value can be converted to a specified engineering unit. The value can be displayed with the physical measurement value of the sensor and be saved into the data file with the converted values.



Trigger function

The trigger in this unit has multiple functions including level trigger of input signal value for each channel.

Trigger action Start or stop capturing data by triggering Trigger source Off, Measured signal level, Alarm, External, Scheduled time, Scheduled day, Elapsed time * When trigger is used for starting action, level of measured signal can be set for each channel. **Threshold** Analog input: High or Rising, Low or Falling, Window-in, Window-out Logic input: H or L (4-channel signal pattern) Pulse input : High or Rising, Low or Falling, Window-in, Window-out Combination: Level OR, Level AND, Edge OR, Edge AND

Calculation function between channels


Four arithmetic operations (Addition, subtraction, multiplication and division) are available using two analog input channels.

* Data can be saved only in GBD file format.



Alarm function & signal output

Threshold of an alarm can be set for each channel. When an alarm occurs, notification is sent by following methods.




Large Easy-to-read 7-inch LCD

Monitor data in multiple methods in addition to digital value display and full waveform display screen.


Y-T waveform monitor screen

Displays data with analog waveform and digital value. Screen can also be split into 1, 2, 4 or 8 zones to display the channels in different zones.




Digital monitor screen

Displays current data in digital value and results of real time statistical calculation. (Function: Maximum, Minimum, Peak-to-peak, and Average) When displays only current data, it can be shown in 1, 2, 4 or 8 zones.



Past waveform monitor screen

Display the past part of the data while capturing data. Execute without stopping measurement and also scroll past data. Data screen can be switched with past and current.



XY graph monitor screen

Emulates the classic XY chart recorder. Also supports features for pen up/down and position movement.





Quick and Easy Set Up Process

Simple operation with cursor and enter keys, and menu-driven operation with six pre-set menu screens: AMP, DATA, DISP, TRIG, I/F (Interface) and OTHER.

Cursor keys

Move between items on the setting screen and move the cursor on the waveform screen.

ENTER key

Determine the item and value selected with the menu.


FUNCTION (FUNC) key

Execute the specified function with this shortcut button. Frequently used function can be preset.



Free-running function

The input signal being captured in real time can be monitored on the measurement or setting screen even if recording has not initiated. The measurement voltage range can be set while watching the waveform.



Other helpful functions

Delivers reliable measurements out at a location with unstable power supply.

Equipped with three types of options for power source, AC adapter, DC input, and battery pack. With a battery pack, GL2000 runs continuously for approximately 3 hours. If an AC power failure occurs, it will automatically switch from the AC adapter to the battery pack. Additionally, when the voltage of the battery pack reaches low, measurement is automatically stopped after saving the data file preserving the accumulated data. (Requires two battery packs (B-569 option) installed.)

Instrument is in compliance with JIS Vibration Test Method for Automobile Type 1 Class A. (Vibration durability test: 5 m/s²)


Carrying case (B-581)

Portable case to store GL2000 and signal input cables for easy handling.

coming soon


Cover (B-579)

GL2000 is shipped with cover attached.



Supports large built-in RAM (4MS/ch) and built-in Flash (4 GB)

Long term recording is made possible with 4 M samples/ch built-in RAM and 4 GB built-in Flash memory. It supports both USB Flash memory and SD Card memory to be used as external storage devices for recorded data for certain sampling intervals.



Approximate recording time

■ 4 channels of analog input. ■ Data is saved as a GBD file.


| Memory type | Data capacity | 1MS/s(1μs) | 100kS/s(10μs) | 1kS/s(1ms) | 1S/s(1s) |
|--|----------------|------------|---------------|----------------|-------------|
| Built-in RAM | 4 M samples/ch | 4 seconds | 40 seconds | 66 minutes | 46 days |
| Built-in Flash memory | 3.9 GB | N/A | N/A | 3 days 19 hrs. | Over 1 year |
| External memory (SD/USB Flash memory)* | 4 GB | N/A | N/A | 4 days 3 hrs. | Over 1 year |

■ 4 channels of analog input with 4 channels of Pulse input. ■ Data is saved as a GBD file.

| Memory type | Data capacity | 1MS/s(1μs) | 100kS/s(10μs) | 1kS/s(1ms) | 1S/s(1s) |
|--|----------------|------------|---------------|----------------|-------------|
| Built-in RAM | 4 M samples/ch | 4 seconds | 40 seconds | 66 minutes | 46 days |
| Built-in Flash memory | 3.9 GB | N/A | N/A | 1 days 12 hrs. | Over 1 year |
| External memory (SD/USB Flash memory)* | 4 GB | N/A | N/A | 1 days 15 hrs. | Over 1 year |

^{*} When using 8 GB or larger memory, the size of data file will be up to 4 GB. The Relay mode enables extended recording time.

Convenient Data Recording Functions






When multiple measurements are executed, recorded data is stored in the next memory block.



Relay mode

Save data to multiple files with specified capturing time or file size (up to 4 GB) until recording data is stopped.



Data backup and hot swaps

The recorded data can automatically save to other storage device at specified regular intervals during data capture. (Maximum sampling speed: 1 kS/s (interval 1 ms) with GBD format, 100 S/s (interval 10 ms) with CSV format)

When the backup destination is set to a SD Flash memory card or a USB Flash memory device, memory device can be exchanged before the memory capacity becomes full using the key operation.

Auto save function

Recorded data saved in a built-in RAM is automatically copied as data file to a built-in Flash memory, SD Flash memory card or USB Flash memory with auto save function. An SD Flash memory card or a USB Flash memory can be used as a backup location when using the built-in RAM. The process will prevent losing any data captured in the built-in RAM by any overwrite or power cycles.


Ring mode

Saves most recent data of specified number after recording stops.

Number of capturing data

1000 to 10000000 data

* When using built-in RAM, 10 to 4000000 data



Example: Number of capturing data : set to 5000 points

Always save the recent 5000 data

(The oldest data is overwritten by the new data.)


Maximum sampling speed: 1MS/s (interval 1 μ s) in built-in RAM, 1kS/s (interval 1 ms) with GBD format in another device, 100S/s (interval 10 ms) with CSV format in another device

Save & replay data in CSV format





Captured data can be saved with GBD (binary) and CSV (text) format. CSV format file can be played on GL2000 and opened with spreadsheet software.



Maximum sampling speed:

1 kS/s (interval 1 ms) with GBD format,

100 S/s (interval 10 ms) with CSV format

Search function





The search function can locate a specific value within the captured data as well as finding abnormal values within data of a long-recorded file.

Search for analog signal levels, logic signal pattern, pulse signal levels or alarm point in captured data.

Analog signal channel

Signal levels in each channel

Search mode: raising, falling, window-in, window-out

Logic signal channel

Signal level (H or L) in each channel


Pulse signal channel

Signal levels in each channel

Search mode: raising, falling, window-in, window-out

Alarm detected point on selected alarm signal output channel

Equipped with Ethernet (LAN) and USB interface to communicate with PC



| Measurement method | Data file format in PC | Available sampling speed |
|---|------------------------|--------------------------|
| Real time measurement Transfer data captured with GL2000 to PC. | Binary or CSV format | 1 ms to 1 min |
| Memory measurement Transfers data to PC after completed capturing data to built-in RAM with GL2000. | Binary format | 1 μs to 1 min |

^{*} Captured data can be saved with storage device on GL2000 and PC simultaneously.

Convenient function with LAN (Ethernet interface) capability

When GL2000 is connected to LAN using the Ethernet interface, networked computer can monitor real-time measured value, transfer files, and change set ups without using application software (GL980_2000-APS software).

Web server function

GL2000 can be controlled externally via a network on the WEB browser, which also supports real-time monitoring and ability to use the menu buttons.


FTP server function

File in available storage device on GL2000 except built-in RAM can be transferred or deleted from the PC.

LAN (Ethernet)


NTP client function


The clock on the GL2000 is periodically synchronized with the NTP server.



Email sending function

Send information when alarm occurs, or when battery is low, or when communication speed drops, or to notify when the space becomes limited on the storage device by an e-mail to specified address. Information can also be sent periodically by settings.





USB Drive Mode to Easily Transfer Files to PC

USB drive mode

The USB drive mode function allows simple data transfer to the PC from built-in Flash memory and SD Flash memory card which acts as USB Flash drive on GL2000. It also allows to add, remove, and delete files from storage device on GL2000 from PC file browsing explorer.

* Built-in Flash and SD, except USB memory device.



Start USB drive mode by turning the power on while pressing START/STOP key.

Move files by drag & drop feature in PC.

^{*} This interface is for connecting directly to PC only.

PC measurement with standard PC software included (GL980_2000-APS)

Multiple measurement screens including Y-T waveform, XY chart

Y-T display

Recorded signal is displayed in waveform (Y-T) and digital value for each channel.


Y-T display (Zone mode)

Screen is divided into multiple zone, and channels can be assigned to each zone.



XY display

Four groups of XY charts are displayed.



Easily Connect to the GL2000 with Quick Set Up Conditions



The settings are divided in to four screens with amp, recording, trigger and other.

Includes free running feature similar to the main unit.


Measurement voltage ranges and other ranges can be set while reading an input signal prior to capturing the data.



GL2000 is recognized automatically by clicking the connection button regardless of Ethernet or USB.

GL2000 supports DHCP





Convenient features from the GL980_2000-APS software

File combine and bind function

Superimpose

Data or file recorded on another unit or time can be imported as additional channels when using a SUPERIMPOSE function.

Link

Captured data in multiple files are connected and saved as new file. It is helpful in reviewing data captured with relay mode.

Measurement parameters of each file must be the same.

Direct Excel function

The GL980_2000-APS software executes recorded data into a file on PC in real time and exports to a specified Excel file at the same time.

This is a valuable tool in creating report requiring post-process calculation with Excel software.


Printing function

The waveform of the playback data can be printed using a default printer. Printing range of the waveform can be set between cursors or all waveforms.

Advanced software GL-Connection (version 2.0)

■ The high-performance software GL-Connection is included as an accessory

Major features Supports connection with other GL units (*) simultaneously Supports up to 20 GL units (*) Screen division function: 4 screens FFT analysis function GL220, GL240, GL820, GL840 series, GL900 series, GL7000 series, GL980 and GL2000 can be connected. Ethernet (LAN) and USB can be mixed for connection between GL unit and PC.



| Item | | | Description |
|-------------------------|---------------------------------------|--------------------------|--|
| Display | Size | | 7-inch TFT color LCD (WVGA: 800 x 480 dots) |
| (LCD) | Informat | ion | Waveform in Y-T with digital values, Enlarged waveforms, |
| | | | Digital values and Real-time statistical result values, XY graph |
| | Languag | e | English, French, German, Spanish, Russian, Chinese, Korean, Japanes |
| Interface | Type | | Ethernet (10 BASE-T/100 BASE-TX), USB2.0 |
| to PC | Function | | Data transfer to PC (up to 1 ms sampling), Control command to GL200 |
| | | t functions | Web server function, FTP server function, NTP client function, DHCP client function, Email send function |
| T.: | USB fund | | USB mode (File transfer and deletion from built-in flash and SD on GL2000 |
| Trigger | Trigger a | | Start or stop capturing data by triggering |
| function | | Stop | Off, Measured signal, Alarm, External, Scheduled time, Scheduled day, Elapsed time |
| | Combina | | Off, Measured signal, Alarm, External, Scheduled time, Scheduled day, Elapsed tim Level OR, Level AND, Edge OR, Edge AND |
| | | Analog (*1) | High or Low in level mode, Rising or Falling in edge mode, Window-in, Window-or |
| | THESHOU | Logic | H or L (4-channel signal pattern) |
| | | Pulse | High or Rising, Low or Falling, Window-in, Window-out |
| | Repeat a | | Off, On (Re-armed automatically) |
| | Trigger I | | Hold off repeat action in specified period |
| | 990 | Mode | Previous start to next start, previous stop to next start |
| | | Time | zero second (no hold off) to 9999 hrs. 59 min. 59 sec |
| | Defection | n accuracy | ± 0.5 % of measurement range |
| | Pre-trigo | | Up to the number of capturing data points (max. 4000000) |
| | | , - | specified in built-in RAM (only when built-in RAM is used) |
| Alarm | Alarm ad | ction | Displays and outputs a signal when alarm is detected |
| function | | Analog input | High, Low, Window-in, Window-out |
| | | Logic input | H or L (signal in each channel) |
| | | Pulse input | High or Rising, Low or Falling, Window-in, Window-out |
| | Combina | | OR (Source channel can be assigned with OR condition to output port |
| | Detection | | Link with analog sampling |
| | Alarm ho | - | On or Off |
| | | on accuracy | ± 0.5 % of measurement range |
| Storagve | Built-in F | RAM | Four million samples for each channel |
| deice | | | 4 M samples x 1 bank, 2 M sample x 2 banks, 1 M samples x 4 banks, 500 k samples x 8 bank |
| | | Capturing data points | Specified 10 to 4000000 |
| | | Data type | Captured data |
| | | Auto-save | Transfer captured data to other devices after capturing is completed (It can be enabled or disable |
| | Built-in F | lash | 4 GB (for capacity of data: approx. 3.9 GB) |
| | | Data type | Captured data, Condition settings, Screen copy |
| | External | USB (*2) | Support USB Flash memory device (*3) by USB2.0 Type A port, Single port, No memory capacity lim |
| | | Data type | Captured data, Condition settings, Screen copy |
| | External | SD CARD (*2) | Support SDHC memory card (up to 32 GB) by SD Card slot, Single slo |
| | | Data type | Captured data, Condition settings, Screen copy |
| Capturing | Mode | | Off (Normal), Ring, Relay |
| mode | Off (Normal) | | Save data between start to stop |
| | Ring (*4 |) | Save most recent data of specified number |
| | | Destination | Built-in RAM, Built-in Flash, USB or SD |
| | | Number of capturing data | 1000 to 10000000 data (*5) |
| | | Sampling | up to 1 MS/s (interval 1 μ s) in built-in RAM, up to 1 kS/s (interval 1 ms) with GBD form |
| | | | in other device, up to 100 S/s (interval 10 ms) with CSV format in other device |
| | Relay | | Save data to multiple files with specified capturing time or file size |
| | | | (up to 4 GB) until recording data is stopped |
| | | Destination | Built-in Flash, USB or SD |
| | | Sampling | up to 1 kS/s (interval 1 ms) with GBD format, up to 100 S/s (interval 10 ms) with CSV form |
| Data backup | Interval | | Off, 1, 2, 6, 12, 24 hrs., specific time, or any time with key operation |
| | | Sampling | up to 1 kS/s (interval 1 ms) with GBD format, |
| | | | up to 100 S/s (interval 10 ms) with CSV format |
| | File destination | | Built-in Flash, USB or SD |
| | | oing external memory | Hot-swapping USB or SD Flash memory with key operation during data backu |
| Search | Function | | Search for specific point in captured data |
| function | Search | Analog | Signal levels in each channel |
| | factor | Logic | 4-channel signal pattern |
| | | Pulse | Rising, Falling, Window-in, Window-out in each channel |
| Calculation | Chatinti | Alarm | Alarm occurring point |
| Calculation function | Statistic | aı | Real-time: Display digital and statistical values at the same time |
| runction | Between channels | | Function: Maximum, Minimum, Peak-to-peak (P-P), Average |
| | | | Replay: Statistical values between cursors in replay captured data |
| | | | Function: Maximum, Minimum, Peak-to-peak (P-P), Average, RMS |
| Scaling (Engir | | | Addition, subtraction, multiplication and division for two analog inputs (only in GBD forma Measured value can be converted to the specified engineering uni |
| ocamiy (Eligii | Analog v | | Converts using four reference points (gain, offset) |
| | Tempera | | Converts using two reference points (gain, onset) |
| | | | Converts using two reference points (offset) Converts using two reference points (gain) |
| Annotation fu | Pulse count | | Comment can be set in each channel, up to 31 alphanumeric |
| ocacion It | | | characters and symbols (Display first 8 characters on screen) |
| Operating en | /ironment | | 0 to 40 °C when driven by AC adapter or battery, 5 to 85 % RH (non condensed |
| Power | AC adap | | 100 to 240 V AC, 50/60 Hz |
| source | | | 8.5 to 24 V DC (required cable option B-514) |
| Jource | DC power | | Two battery packs (option B-569) required |
| Power | Battery pack AC adapter (in 240 V AC) | | Approx. 39 VA (59 VA while charging battery) with disabling screen save |
| | αυαμ | (III 2 TO V MC) | Approx. 34 VA (55 VA while charging battery) with disabiling screen save |
| | DC deixe | (24 V) | |
| consumption | DC drive | (24 V) | Approx. 0.5 A (0.81 A while charging battery) with disable screen sav |
| | | | Approx. 1. A (Cannot charge battery) with disable screen saver |
| | DC delice | | Approx. 1 A (Cannot charge battery) with disable screen saver |
| | DC drive | e (12 V) | Approx O.SE A (Connet shows bettern) 111 |
| | | | 7 7 7 |
| | | (12 V) (8.5 V) | Approx. 1.46 A (Cannot charge battery) with disable screen save |
| consumption | DC drive | e (8.5 V) | Approx. 1.46 A (Cannot charge battery) with disable screen saved Approx. 1.22 A (Cannot charge battery) with enabling screen saved |
| consumption | DC drive | e (8.5 V) | Approx. 1.46 A (Cannot charge battery) with disable screen save Approx. 1.22 A (Cannot charge battery) with enabling screen save Approx. 260 x 161 x 83 mm (with the cover) |
| | DC drive | e (8.5 V) | Approx. 0.85 A (Cannot charge battery) with enabling screen save Approx. 1.46 A (Cannot charge battery) with disable screen save Approx. 1.22 A (Cannot charge battery) with enabling screen save Approx. 260 x 161 x 83 mm (with the cover) Approx. 1.7 kg (the cover is attached, AC adapter and battery are not included Compatible with JIS Vibration test method for automobile Type 1 Class. |

| Analog input | specifications | S | | | |
|--|-----------------|---|--|------------------------------------|--|
| Item | | | Description | | |
| Number of input channels | | 4 channels | | | |
| Type of input | terminal | | Isolated BNC connector and Screw terminal (M3.5 screw) (*6) | | |
| Input method | | | All channels isolated unbalanced in | nput, Simultaneous sampling | |
| Sampling spec | ed (interval) | | 1 M Samples/s to 1 Sample/min (| 1 μs to 1 min) and External (*7) | |
| | Sampling int | erval | 1, 2, 5, 10, 20, 50, 100, 200, 50 | 0 μs, | |
| | | | 1, 2, 5, 10, 20, 50, 100, 200, 500 | ms, 1, 2, 5, 10, 20, 30 sec, 1 min | |
| | | | * When using built-in RAM: 1 µs to 1 m | | |
| Frequency res | sponse | | DC to 200 kHz (within +1/-4 dB) | | |
| Measurement | r e | :) | 20, 50, 100, 200, 500 mV, 1, 2, | 5. 10. 20. 50. 100. 200. 500. | |
| range | | • | 1000 V, and 1-5V F.S. * Max. rate | | |
| 9- | DC-RMS | | 10, 25, 50, 100, 250, 500 mV rn | | |
| | (DC coupling | n and | | . rated safety voltage: 600 V rms | |
| | rms value m | - | Crest Factor : in 1000 V range, up to 1.4 | | |
| | TITIS VAIGE III | cus.) | • Frequency response : 20 Hz to | | |
| | | | Measures the accumulated value | | |
| | | | in effective value, that is a true-F | | |
| | Tommoret | | | | |
| | Temperatur | е | Thermocouple: K, J, E, T, R, S, B, I | <u> </u> | |
| F'1. /1 | Humidity | | 0 to 100 % RH - using the humidi | | |
| Filter (Low pa | | | Off, Line (1.5 Hz), 5, 50, 500 Hz, | | |
| A/D converte | | | 16-bit (effective resolution: 1/40 | 000 of the measuring full range) | |
| Measurement | | | ± 0.25% of Full Scale | | |
| accuracy (*8) | Voltage (RM | IS) | ± 1.5% of Full Scale (Sine wave in | 20 Hz - 10 kHz) | |
| | Temperature | Туре | Measurement range | Measurement accuracy | |
| | (Thermocouple) | R/S | 0 ≤ TS ≤ 100 °C | ± 7.0 °C | |
| | (*9) | | 100 < TS ≤ 300 °C | ± 5.0 °C | |
| | | | R: 300 < TS ≤ 1600 °C | ± (0.05 % of reading + 3.0 °C) | |
| | | | S: 300 < TS ≤ 1760 °C | ± (0.05 % of reading + 3.0 °C) | |
| | | В | 400 ≤ TS ≤ 600 °C | ± 5.5 ℃ | |
| | | | 600 < TS ≤ 1820 °C | ± (0.05 % of reading + 3.0 °C) | |
| | | К | -200 ≤ TS ≤ -100 °C | ± (0.05 % of reading + 3.0 °C) | |
| | | | -100 < TS ≤ 1370 °C | ± (0.05 % of reading + 2.0 °C) | |
| | | Е | -200 ≤ TS ≤ -100 °C | ± (0.05 % of reading + 3.0 °C) | |
| | | | | ± (0.05 % of reading + 2.0 °C) | |
| | | Т | -200 ≤ TS ≤ -100 °C | ± (0.1 % of reading + 2.5 °C) | |
| | | | | ± (0.1 % of reading + 1.5 °C) | |
| | | J | -200 ≤ TS ≤ -100 °C | | |
| | | | | ± 2.7 ℃ | |
| | | | | ± (0.05 % of reading + 2.0 °C) | |
| | | N | | ± (0.1 % of reading + 3.0 °C) | |
| | | 14 | | ± (0.1 % of reading + 3.0 °C) | |
| | | W | | | |
| | | VV | | ± (0.1 % of reading + 2.5 °C) | |
| D. I. Commission | etion | | Reference Junction Compensation | (K.J.C.) accuracy: ± 1.0 °C | |
| R.J. Compensation | | Internal or External | with many apprentiants for the same | | |
| Burnout | | Detecting burnout of Thermocouple v | viui menu operation in free-run mode | | |
| Input impedance | | 1 MΩ ±5% | | | |
| Signal source impedance | | up to 1 kΩ | | | |
| Maximum | | | 20 mV to 2 V range: 30 V DC/AC, | 5 V to 1000 V range: 600 V DC/AC | |
| input voltage Between channels (-) - (-) terminals | | | | | |
| Between channel - GND | | 600 V DC/AC (CAT III) | | | |
| Isolation resistance | | Min. 50 M Ω (at 500 V DC) with between input and GND | | | |
| Common-mod | le rejection ra | atio | Min. 90 dB (50/60 Hz, signal source impedance: max. 300 Ω) | | |
| Signal-noise r | atio (S/N) | | 20 mV range : - 40 dB (when input terminals + and - are shorted) | | |
| | | | Other range : - 50 dB (when input | terminals + and - are shorted) | |
| | | | | - | |
| | | | | | |

| e | | | |
|------------------------------|----------------|--------------------|--|
| | & output | signal specificati | |
| Item | | | Description |
| External | Input (*1 | -, , | Logic or Pulse (4 channels), Trigger or Sampling (1 channel) |
| input/output | Output (| *10, *12) | Alarm (4 channels) or Trigger (1 channel) with Alarm (3 channels) |
| Input signal | Logic | Voltage range | 0 to +30 V (common ground) |
| specification | and | Threshold | Approx. +2.5 V |
| | Pulse | Hysteresis | Approx. 0.5 V (+2.5 to +3 V) |
| | External | Voltage range | 0 to +30 V (common ground) |
| | trigger and | Threshold | Approx. +1.9 V |
| | sampling | Hysteresis | Approx. 0.2 V (+1.9 to +2.1 V) |
| Logic measurement | | | Measures the status (H or L) of the signal input to each channel |
| Pulse | Measurement | | Counts pulse signals input to each channel |
| measurement | Pulse cou | nt detection cycle | 10 μs to 1 hr. (Set separately from analog signal sampling interval) |
| Maximum pulse input | | n pulse input | Maximum input frequency : 100 kHz, |
| | | | Maximum count number : 15 M count (24 bit counter) |
| | Measurer | ment mode | Rotation: Counts the number of pulses per detection cycle |
| | | | and then converts measured value to rotation in rpm |
| | | | • Span: 0 to 500 M rpm/F.S. |
| | | | Accumulating: Accumulates the number of pulses count |
| | | | per detection cycle from the start of measurement |
| | | | Span: 0 to 20 M count/F.S. (Span is set automatically) |
| | | | Instant: Counts the number of pulses per detection cycle |
| | | | Span: 0 to 20 M count/F.S. |
| External trigger input (*10) | | *10) | Executes specified trigger action |
| External samp | ling input | (*10) | Executes sampling of measurement signal with each external sampling signal |
| | | | Maximum input frequency: 100 kHz (Time error: 1 µs or less) |
| Output | Alarm ou | tput | Open collector (pull-up to 5 V with 10 kΩ resistor) |
| signal | | • | Maximum load is the 24 V and 100 mA |
| | Trigger output | | When a trigger is detected, output terminal releases approximately 500 µs width pulse (Low active) |

| Software spe | cifications | | | |
|-----------------|------------------------|---|--|--|
| Item | | Description | | |
| Model name | | GL980_2000-APS | | |
| Supported OS | S (*13) | Windows10, 8.1, 8, 7 (SP1 or later) | | |
| Functions | | Control GL980 and GL2000, Real-time data capture, Replay data, | | |
| | | and Data format conversion | | |
| Supported de | vice | 1 unit of GL980 or GL2000 | | |
| Settings cont | rol | Input condition, Capturing condition, Trigger/Alarm condition, other | | |
| Transfer of | In memory capturing | Transfer the captured data to a PC sequentially while data is saved in built-in RAM on GL2000 | | |
| captured data | with GL2000 | • Sampling interval: 1 μs to 1 min | | |
| | In real time capturing | Transfer the captured data to a PC while data is saved in built-in flash memory, | | |
| | | SD or USB on GL2000 | | |
| | | Sampling interval: 1 ms to 1 min saved in GBD and CSV format | | |
| Displayed info | ormation | Analog waveform, Logic waveform, Pulse count waveform, Digital value | | |
| Display mode | | Waveform in Y-T with digital values, Enlarged waveforms, | | |
| | | Statistical calculation result values and history, XY graph | | |
| File operation | 1 | Converting data format to CSV from GBD binary with data between cursors or all data | | |
| Past data scr | een function | Displays the current data or past part of data by switching. | | |
| | | Available at sampling speed 1 kS/s to 1 S/m (1 ms to 1 min sampling interval) | | |
| Statistical cal | culation | Maximum, Minimum, Average and Peak-to-peak (p-p) value during data capturing | | |

| Battery pack B-569 (option) Specifications | | | |
|--|--|--|--|
| Item | Description | | |
| Capacity | 7.2 V, 2900 mAh | | |
| Battery operating time | Approx. 3 hrs. in displayed signal (LCD: max. brightness) | | |
| | Approx. 5 hrs. in screen saver mode (no display) | | |
| | * When two battery packs are installed in GL2000. | | |
| | Condition: 1 sample per second (1 s), saving captured data to built-in Flash, | | |
| | use two fully charged battery packs, temperature is 25 °C | | |
| Method of charging | Charging on GL2000 | | |
| Charging time | Approx 10 hrs. (charging two batteries) | | |
| Other functions | If an AC power failure occurs, it will automatically switch | | |
| | from the AC adapter to the battery pack. (AC adapter priority use) | | |
| | When the voltage of the battery pack reaches low, the measurement | | |
| | is automatically stopped after saving data file preserving the accumulated data. | | |

- (*1) It can set for each channel.
- File size of captured data is up to 4GB in each file.
- (*2) (*3) Standard USB memory devices are required.
- Required minimum capturing time is 15 seconds in GDB format, 30 seconds with CSV format.
- (*5) When using built-in RAM, 10 to 4000000 data
- Connections can be made individually to BNC terminal or M3.5 screw terminal.
- Required Input/Output cable for GL series (B-513) option for connecting signal.
- Subject to the following conditions:
 Room temperature is 23 °C ± 5 °C.
- When 30 minutes or more have elapsed after power has turned on.
 Filter is set to Line (1.5 Hz) in DC measurement and temperature.
- GND terminal is connected to ground.
- It is placed vertically.
- Average of the measured values is used.

 Wire size of Thermocouple used is 0.32mm diameter in the T and K type, and 0.65mm diameter in other types.
- (*10) Required Input/Output cable for GL series (B-513) option for connecting signal.
- (*11) Select either Logic input (4 channels) or Pulse input (4 channels), select either external Trigger input or Sampling input.
- (*12) Select either Trigger output (1 channel) or Alarm output (1 channel). Available 3 channels Alarm output always.
- (*13) Graphtec does not support software/driver used with operating systems that have become obsolete and are no longer supported by the OS developer. In the Windows 7, edition of Ultimate, Enterprise, Professional and Home Premium are supported.

Clip, Alligator

(small size) RIC-144A

Clip, Alligator (middle size) RIC-145

Clip, Grabber RIC-146

- AC adapter with power cable
- CD-ROM (PC application software, User manual)
- Tilt stand set (including mounting screws M4) • Ferrite core (attach to cable for radiation reduction)
- Quick start guide and Safety guide
- Cover (attached to the main body)

Humidity sensor B-530

Shunt resistor B-551

• Screws (M3.5) for input terminal

| Options and Accessories Item | Model No. | Description | | |
|--|-----------|---|--|--|
| Input/Output cable for GL | B-513 | 2 m long (no clip on end of cable) | | |
| DC drive cable | B-514 | 2 m long (no clip on end of cable) | | |
| Humidity sensor | B-530 | With 3 m long signal cable (with power plug) | | |
| Shunt resistor | B-551 | 250 ohms (Converts signal from "4-20mA" to "1-5V" .) | | |
| Battery pack | B-569 | Rechargeable Lithium-ion battery (7.2 V, 2900mAh) | | |
| Bracket for DIN rail | B-570 | Bracket for DIN rail (GL2000 main body), Build-to-order | | |
| Cover | B-579 | Rubber protector (for replacement) | | |
| Carrying case | B-581 | Comming soon | | |
| Input cable, Safe probe - BNC | RIC-141A | Insulated, 1:1 (42pf), 1.2 m long, 300 V DC, CAT II | | |
| Input cable, BNC - BNC | RIC-142 | Insulated, 1.5 m long, 1000 V DC, CAT II | | |
| Input cable, Banana - BNC | RIC-143 | Insulated, 1.6 m long, 600 V DC, CAT II | | |
| Clip, Alligator (small size) | RIC-144A | For RIC-143, Aperture 11 mm, 300 V DC, CAT II, Max. 15 A | | |
| Clip, Alligator (middle size) | RIC-145 | For RIC-143/147, Aperture 20 mm, 1000 V DC, CAT II, Max. 32 A | | |
| Clip, Grabber | RIC-146 | For RIC-143/147, Aperture 5 mm, 1000 V DC,CAT III, Max. 1 A | | |
| Input cable, Banana - BNC (Hi-voltage) | RIC-147 | Insulated, 1.6 m long, 1000 V DC, CAT II | | |
| Input terminal adapter | SMA-102 | Banana (receptacle) to BNC (plug), Insulated | | |
| AC Adapter | ACADP-20 | Input: 100 - 240 V AC, Output: 24 V DC | | |
| Input Cable, Safe probe - BNC RIC-141A Input cable, BNC - BNC RIC-142 Input cable, BNC - BNC RIC-142 | | | | |

Input cable, Banana - BNC RIC-143

Input cable, Banana - BNC

(Hi-voltage) RIC-147



Due to the possibility of equipment or PC failure, the data files on the instrument are not guaranteed to hold memory.

Please make a backup of data whenever possible to avoid data loss.

Brand names and product names listed in this brochure are the trademarks or registered trademarks of their respective owners.

Specifications and details are subject to change without notice. For additional information, please check our web site or contact your local representative.

Use equipment correctly and safely!

 \cdot Use only in accordance with product's user manual.

• To avoid malfunction or an electric shock by current leakage or voltage, please ensure ground connection and use according to the specifications.



503-10 Shinano-cho, Totsuka-ku, Yokohama 244-8503, Japan Tel: +81-45-825-6250 Fax: +81-45-825-6396

Email: webinfo@graphtec.co.jp

